

## How to mount sensors

Before starting the process of mounting the sensors, please make sure the gateway and access point are connected. You can find that manual here:

<https://flowscape.zendesk.com/hc/en-us/articles/360011250319-Gateway-and-access-point-installation>

### Mounting Procedure

- Turn on the sensor
  - For battery powered sensors: Push power switch on the left side ON (switch shall be up)
- Verify the LED on the front panel is lit within 10 seconds. If the LED has not made any indication within 10 seconds, check batteries or external power.
- Dry target surface with a cloth to remove dust, dirt, and grease
- Place sensor by removing the non-stick film on the back of the sensors sleeve and place it into position by pressing FIRMLY on the gray sleeve for 10 seconds (if adhesive tape is used)
  - After 10 seconds, the adhesive tape is strong enough to hold the sensor. Full adhesiveness is reached after 72 hours.

### Room Mounting

- Place sensors along walls at about 150-170 cm (60-70 inches) from floor
- Face away from door to avoid detecting people walking outside the room (Recommended to place on door frame)
- Face away from windows to avoid direct sunlight
- Target wood, plastic, or metal surfaces that are flat
- Avoid wall papers as they may break if sensor must be removed
- Avoid painted walls when using adhesive tape as modern paint is efficient in repelling adhesive tape

### Table Mounting

- Assemble under a tabletop approx. 30 cm from edge of table
  - See drawing below

*Table from above*



