

Billboard Assembly

Please note, if you are mounting the billboard screen on the wall you can skip step 1 – 4 below.
Please follow separate instruction for how to mount the screen on the wall.

1. Assemble the ELO Touch Wayfinder Floor stand (Instructions can be found here: <https://support.flowscape.se/hc/en-us/articles/360017088040-Floor-Stand-Assembly>)
2. Put a power strip inside the leg of the ELO Touch Wayfinder and pull the plug under the foot of the floor stand to be able to plug it in the power socket.
3. Pull an Ethernet cable under and up the leg of the ELO Touch Wayfinder Floor stand
4. Place the NUC-computer on the lower “shelf” on the ELO Touch Wayfinder Floor stand laying on the side.
5. Connect the power (DC Input jack) of the NUC computer to the power strip.
6. Connect the Ethernet cable to the RJ45 socket on the NUC Computer .
7. Place the ELO screen on top of the floor stand. Before laying it down, connect the following cables.
 - a. Power between ELO screen and power strip
 - b. Touch USB between ELO screen and NUC Computer
 - c. HDMI between ELO screen and NUC Computer
8. Put the screen down.
9. Connect the power and the billboard should turn on automatically.