

Busy Light mounting guide

Before starting the process of mounting the busy light, please make sure the gateways are connected. You can find that manual here:

<https://support.flowscape.se/hc/en-us/articles/360014274320>

Mounting Procedure – Room

- Mount the wall-bracket at wanted height outside the room
- Connect the USB Data Cable for power supply.
- Attach the supplied adhesive tape on the bottom of the Busy Light
- Attach to wall mount

Mounting Procedure – Desk

- Connect the USB Data Cable for power supply.
- Attach the supplied adhesive tape on the bottom of the Busy Light
- Place Busy Light on a visible location on the desk using the adhesive tape.